

YARD INFORMATION & RULES

YARD NAME: PORT OF RICHMOND	CITY: RIC	HMOND STATE: CA
ADDRESS: 980 HENSLEY STREET	CONTACT:	INSPECTOR (951) 622-0701
RAIL: BNSF DAYS / HOURS: \	VERIFICATION: 24 / 7	
NOTES: *** ALL DAMAGES REGARDLESS	OF SEVERITY MUST I	BE VERIFIED IN BAY. ***

INSPECTIONS & REPORTING DAMAGES

- 1. ALL SPECIFIC YARD RULES MUST BE FOLLOWED. IF YARD RULES ARE NOT FOLLOWED EXACTLY, YOU MAY BE LIABLE FOR DAMAGE CLAIMS. THIS INCLUDES CONFIRMING THE FULL VIN MATCHES, GETTING **VERIFICATION** FOR PRE-EXISTING DAMAGES AND LEAVING BAY TAG AT GUARD SHACK. THE SECURITY GUARD IS NOT AN INSPECTOR.
- 2. IF A VEHICLE HAS DAMAGE THAT NEEDS TO BE VERIFIED AND THERE IS NOBODY AVAILABLE TO VERIFY IT, DO NOT TAKE THE UNIT. IF A VEHICLE NEEDS TO BE SWAPPED OUT or REMOVED FROM THE LOAD, CALL PROFICIENT AUTO TRANSPORT DISPATCH (904) 638-6368.
- 3. ALL VEHICLES MUST HAVE COMPLETE INSPECTIONS DONE PRIOR TO LOADING (IN BAY), INCLUDING NOTING ALL DAMAGES WITH THE MANDATORY MAGNUS APP (USING THE AIAG DAMAGE CODES) AND UPLOADING SUPPORTING PHOTOS. IT IS THE DRIVER'S <u>RESPONSIBILITY</u> TO ENSURE THAT <u>ALL</u> DAMAGES NOTED ARE CORRECT.
- 4. ALL YARD EXIT SHEETS MUST BE UPLOADED VIA THE MANDATORY MAGNUS APP. IT IS THE DRIVER'S RESPONSIBILITY TO PROVIDE THIS.
- 5. USE STANDARD SAFETY YARD RULES/ETIQUETTE.
 - a. HIGH VISIBILITY CLOTHING IN ALL YARDS
 - **b.** DRIVE WITHIN POSTED SPEED LIMITS
 - c. HORNS/FLASHERS TO BE USED AT ALL TIMES IN YARDS

*** CONTACTS ***

3rd PARTY INSPECTOR (INTERRAIL INSPECTIONS) (951) 622-0701 miraloma@interrail-transport.com RAMP OPERATOR (INTERRAIL TRANSPORT) (951) 681-0780 miraloma@interrail-transport.com



BNSF YARD RULES - DAMAGES

ALL applicable rules and laws must be followed.

- 5 MPH speed limit in check point area; 15 MPH on the facility
- Drivers must wear a reflective shirt or vest while outside of their vehicle.
- Enclosed shoes must be worn.
- Obey traffic control instructions and signs
- No alcohol, firearms, or illegal drugs
- No shuttling in customer vehicles
- No cutting through bays
- If a unit is moved, and it is not yours, report it to the Terminal Manager
- Back out of bays, do not drive through
- Do not cut through bays, use the aisles
- Load/Unload only in designated areas
- Drivers must report all spills or leaks to the Terminal Manager
- All vehicles are subject to search
- Stay clear of rail unloading/loading area and tracks
- Do not cross railroad tracks when locomotives are in the yard
- Stop for flares and flashing lights
- Yield to trains, yard equipment and pedestrians
- Keep off trains and yard equipment
- Present vehicle operator license and photo ID on demand
- ALL DAMAGES (REGARDLESS OF SEVERITY) MUST BE REPORTED AND VERIFIED.
- No trespassing or loitering
- Bay tickets and load sheets must be left in the designated area or with security prior to exit
- No overnight parking is authorized without prior approval
- Passengers and pets are not allowed
- Failure to follow any rule will result in revocation of driving privileges at all BNSF Terminals



AIAG DAMAGE CODES

MANDATORY MAGNUS APP MUST BE USED ON ALL LOADS

AIAG DAMAGE AREA CODES - 1ST & 2ND DIGITS					
01 ANTENNA/ANTENNA BASE	34	REAR - MULTIMEDIA and/or SPEAKERS	67	OPEN (DO NOT USE)	
02 BATTERY (SMALL/LOW VOLTAGE)	35	ROCKER PANEL/OUTER SILL - LEFT	68	CARPET - FRONT	
03 BUMPER/COVER/EXTERIOR - FRONT	36	ROCKER PANEL/OUTER SILL - RIGHT	69	CENTER POST - RIGHT	
04 BUMPER/COVER/EXTERIOR - REAR	37	ROOF	70	CENTER POST - LEFT	
05 BUMPER GUARD/STRIP - FRONT	38	RUNNING BOARD/STEP - LEFT	71	CORNER POST/PILLAR - REAR LEFT	
06 BUMPER GUARD/STRIP - REAR	39	RUNNING BOARD/STEP - RIGHT	72	LEFT FRONT TIRE	
07 DOOR, BACK CARGO - RIGHT	40	SPARE TIRE	73	LEFT FRONT WHEEL/RIM	
08 DOOR, BACK CARGO - LEFT	41	CHARGING CABLE FOR BATTERY ELEC. VEH.	74	LEFT REAR TIRE	
09 DOOR, CARGO (SLIDING) - R/L	42	SPLASH PANEL/SPOILER - FRONT	75	LEFT REAR WHEEL/RIM	
10 DOOR, LEFT FRONT	43	OPEN (DO NOT USE)	76	RIGHT REAR TIRE	
11 DOOR, LEFT REAR	44	GAS TANK	77	RIGHT REAR WHEEL/RIM	
12 DOOR, RIGHT FRONT	45	TAIL LIGHT/HARDWARE	78	RIGHT FRONT TIRE	
13 DOOR, RIGHT REAR	46	TRUCK CAB - REAR	79	RIGHT FRONT WHEEL/RIM	
14 FENDER, LEFT FRONT	47	CORNER POST/PILLAR - REAR RIGHT	80	COWL	
15 QTR. PANEL or PICK-UP BOX - LEFT	48	INTERIOR TRIM PANEL - LEFT FRONT	81	GAS/BATTERY DOOR/FUEL CAP COVER	
16 FENDER, RIGHT FRONT	49	BATTERY (LARGE/HIGH VOLTAGE)	82	FENDER - LEFT REAR	
17 QTR. PANEL or PICK-UP BOX - RIGHT	50	RIGHT FRONT INTERIOR TRIM PANEL	83	FENDER - RIGHT REAR	
18 FRONT FLOOR MATS	51	TONNEAU COVER	84	TOOLS/JACKS/SPARE-TIRE MOUNT & LOCK	
19 REAR FLOOR MATS	52	DECK LID/TAILGATE/HATCHBACK	85	IMPROPER CHOCK SECUREMENT	
20 GLASS WINDSHIELD	53	SUN ROOF/GLASS ROOF	86	PARKING SONAR SYSTEM	
21 GLASS - REAR	54	UNDERCARRIAGE/OTHER	87	A-PILLAR/CORNER POST - FRONT LEFT	
22 GRILLE	55	CARGO AREA	88	A-PILLAR/CORNER POST - FRONT RIGHT	
THROW-INS/LOOSE ITEMS (ACCESSORIES,	56	CONVERTIBLE TOP	89	TRAILER HITCH, WIRING HARNESS, TOW HOOKS	
HEADPHONES, CORDS, LIGHTER) 24 HEADLIGHT/COVER/TURN SIGNAL	57	SHEEL COVERS/CAPS	90	FRAME	
25 LAMPS, FOG/DRIVING/SPOT LIGHT		OPEN (DO NOT USE)		EXHAUST SYSTEM	
26 HEADLINER		WIPERS - ALL			
			-	LICENSE BRACKET	
27 HOOD 28 KEYS		JUMPED CHOCKS		STEERING WHEEL/AIRBAG	
		BOX INTERIOR - PICK-UP TRUCK	_	SEAT - LEFT FRONT	
29 KEYLESS REMOTE/KEY FOBS		ENTIRE VEHICLE		SEAT - RIGHT FRONT SEAT - REAR	
30 MIRROR, OUTSIDE - LEFT 31 MIRROR, OUTSIDE - RIGHT		RAILS, TRUCKBED/LIGHT BAR DEFLECTOR/SPOILER - REAR	-	CARPET - REAR	
32 MAJOR DAMAGE (DO NOT USE)		LUGGAGE RACK/STRIPS/DRIP RAIL		INTERIOR	
33 FRONT - MULTIMEDIA and/or SPEAKERS		DASH/INSTRUMENTAL PANEL		ENGINE COMPARTMENT, OTHER	
33 FRONT - MOLTIMEDIA AND/OF SPEAKERS	00	DASH/INSTRUMENTAL PANEL	33	ENGINE COMPARTMENT, OTHER	
AIAG DAMAGE TYPE CODES - 3RD & 4TH DIGITS					
01 BENT	12	SCRATCHED - NOT GLASS	24	MARKER LIGHT DAMAGED	
02 INOPERABLE		TORN	25	DECAL/PAINT STRIPE CONTAMINATION	
03 CUT		DENTED - PAINT or CHROME NOT DAMAGED	_	CONTAMINATION - EXTERIOR	
04 DENTED - PAINT or CHROME DAMAGED		FULL BODY CAR COVER - DAMAGED (WRAP)		FLUID SPILLAGE - EXTERIOR	
05 CHIPPED - NOT GLASS or PANEL EDGE		THERMAL EVENT/FIRE	-	THEFT/VANDALISM	
06 CRACKED - NOT GLASS		MOLDING/EMBLEM/WEATHER-STRIP DAMAGED			
07 GOUGED		MOLDING/EMBLEM/WEATHER-STRIP LOOSE	-	INCORRECT PART OR OPTION NOT AS INVOICED	
08 MISSING		GLASS - CRACKED		HARDWARE - DAMAGED	
09 SCUFFED		GLASS - BROKEN	_	HARDWARE - LOOSE/MISSING	
10 STAINED or SOILED - INTERIOR		GLASS - CHIPPED			
11 PUNCTURED		GLASS - SCRATCHED			
AIAG DAMAGE SEVERITY CODES - 5TH DIGIT					
01 DAMAGE UP TO & INCLUDING 1" IN LENGTH/DIAMETER - LESS THAN 2.5 CM					
02 DAMAGE OVER 1" UP TO & INCLUDING 3" IN LENGTH/DIAMETER - 2.5 CM UP TO 7.5 CM					
03 DAMAGE OVER 3" UP TO & INCLUDING 6" IN LENGTH/DIAMETER - 7.5 CM UP TO 15 CM					
04 DAMAGE OVER 6" UP TO & INCLUDING 12" IN LENGTH/DIAMETER - 15 CM UP TO 30 CM					
05 DAMAGE OVER 12" IN LENGTH/DIAMETER - 30 CM AND OVER					
06 MISSING/MAJOR DAMAGE					
				Jun-23	

